



1 Barrel	30 Plunger Pin	58 Adjusting Screw (B)	85 -
2 -	31 Safety	59 Spring, Trigger Pull	86 -
3 -	32 Safety Pawl	60 Adjusting Screw, Trigger	87 Front Spacer
4 -	33 Safety Pawl Spring	Pull (A)	88 Frame Screw, Front
5 -	34 Roller	61 Locking Nut	89 Rear Spacer
6 -	35 Safety Pawl Pin (2x)	62 Adjusting Screw, Trigger	90 Frame Screw, Rear
7 -	36 Sear	Overtravel (C)	91 Trigger Guard
8 -	37 Sear Stop	63 Locking Nut	92 Magazine Latch
9 -	38 Sear Spring	64 Nylon Pin (2x)	93 Magazine Latch Spring
10 -	39 Sear Pin (2x)	65 Trigger Mechanism	94 Magazine Latch Pin
11 -	40 Bolt Stop	66 Screw	95 Magazine Catch
12 Receiver	41 Bolt Stop Spring	67 Spring Washer	96 Magazine Catch Spring
13 Bolt	42 Safety Pin	68 Stock	97 Magazine Catch Pin
14 Bolt Handle Knob	43 Retaining Plate	69 -	98 Magazine Shell
15 Extractor	44 Ejector	70 Buttplate Assy	99 Magazine Floor Plate
16 Extractor Collar	45 Ejector Pin	71 -	100 Floor Plate Lock
17 Firing Pin	46 Ejector Spring	72 -	101 Magazine Spring
18 Firing Pin Spring	47 Ball	73 -	102 Follower
19 Support, Firing Pin Spring	48 Trigger Housing	74 -	103 Magazine Ejector
20 Nut, Firing Pin Spring	49 Trigger	75 -	104 Magazine Ejector Spring
21 Cocking Piece	50 Trigger Lever	76 -	105 Magazine Ejector Pin
22 Pin, Firing Pin Nut	51 Trigger Lever Pin	77 -	106 Trigger Spring
23 Cap	52 -	78 -	107 Cheekpiece Assy
24 Bolt Sleeve	53 Adjusting Screw, Set	79 -	108 Muzzle Cover
25 Disassy Catch	Trigger	80 -	
26 Disassy Catch Spring	54 Set Trigger Lever	81 -	
27 Disassy Catch Pin	55 Spring, Set Trigger Lever	82 -	
28 Disassy Catch Plunger	56 Pin	83 -	
29 Plunger Spring	57 Retaining Ring (2x)	84 -	

The numbers marked with dash (-) are stated here for the purpose of conformity with the lists of other rifle parts only.